

Cortek srl

Cortek Aqua Mechanical Keyboard Fast Manual

Thanks for your purchase of our product. This product is built in accordance with the regulations of the European Community and follows CE and RoHS directives.
For features and specifications you can refer to www.cortek.it

Manuale rapido per tastiera meccanica Cortek Aqua

Grazie per aver acquistato questo prodotto. Questo prodotto e' stato costruito seguendo le regole della comunita' europea e le direttive CE and RoHS.
Troverai caratteristiche e specifiche anche su : www.cortek.it

Immagine della versione Ocean Aqua / Ocean Aqua version image



General informations

The Aqua keyboard is a very high quality product. It is a hot swap gasket mechanical keyboard with 68 keys and transparent structure, communication is Bluetooth, RF or cable.

The switches mounted are the Cortek Phantom Silent Linear or the Kailh Box White Click-bar. The version with the Cortek Silent switches, the 6 gaskets and the 4 internal absorbent layers give a particularly soft and pleasant touch. The version with the Kailh Box White switches is for click lovers, as it is well known that the best click on the market is precisely that of the Kailh Box switches in the various versions, this "Click-Bar" technology being superior to the others. The keys are very high quality PBT with sublimation on 5 sides and, in addition to the US layout, they have Italian characters printed on the front. In the package there are more keys and also four thematic keys designed on the 5 sides: space-bar, enter, long fn, short fn.

The lighting is RGB. Aqua is equipped with software that can be downloaded from the Cortek website. The package includes a transparent keyboard cover and a puller for keys and switches.

Commands

Up FN :

Win : FN + 1..0 = F1..F10, FN+- = F11, FN+ += = F12

Mac : FN + 1.00 = -brightness, +brightness, task switch, search,--,--,previous, Play, Next, Mute, FN+- = -volume, FN+ += = +volume.

FN+A = switch to Win, FN+S = switch to Mac, FN + SPACE (3 sec) = reset, FN+WIN = lock/unlock, FN + ARROWS = +- backlight and +- effects speed, FN+DEL = INS, FN + PGUP = HOME, FN + PGDN = END, FN+[{ = 19 light modes, FN+ }] = light colors.

Down FN :

FN + 0..1 = -brightgness, +brightness, task switch, search(Win) / back to desktop(Mac), email(solo Win), Lock(Win) / search(Mac), previous, platy, next, mute

FN + - = -volume, FN + += = +volume, FN + , = calculator(solo Win).

Connessioni

For Bluetooth: set the switch to BT, then press FN up +Q/W/E for 5 seconds until a flash appears (entering pairing).

For RF 2.4Ghz: put the switch on BT, then press FN up + P for 5 seconds until a flash appears (locked), then insert the key into the peripheral.

For cable connection, set the switch to OFF.

Informazioni generiche

La tastiera Aqua e' un prodotto di altissima qualita'. Si tratta di una tastiera meccanica gasket hot swap con 68 tasti e struttura trasparente, la comunicazione e' Bluetooth, RF o con cavo.

Gli switch montati sono i Cortek Phantom Silent Linear o i Kailh Box White Click-bar.

La versione con gli switch Cortek Silent, le 6 guarnizioni (gasket) e i 4 strati interni assorbenti danno un tocco particolarmente morbido e piacevole. La versione con gli switch Kailh Box White e' per gli amanti del click, come e' risaputo il click migliore del mercato e' appunto quello degli switch Kailh Box nelle varie versioni, essendo questa tecnologia "Click-Bar" superiore alle altre. I tasti sono PBT di altissima qualita' con sublimazione su 5 lati e, oltre al layout USA, hanno frontalmente stampati i caratteri italiani. Nella confezione si trovano piu' tasti e anche quattro tasti tematici disegnati sui 5 lati : space-bar, enter, fn lungo, fn corto.

L'illuminazione e' RGB. Aqua e' provvista di software scaricabile dal sito Cortek. Nella confezione si trovano inclusi un copritastiera trasparente e un estrattore per tasti e switch.

Comandi

FN in alto :

Win : FN + 1..0 = F1..F10, FN+- = F11, FN+ += = F12

Mac : FN + 1.00 = -brightness, +brightness, task switch, search,--,--,previous, Play, Next, Mute, FN+- = -volume, FN+ += = +volume.

FN+A = switch to Win, FN+S = switch to Mac, FN + SPACE (3 sec) = reset, FN+WIN = lock/unlock, FN + ARROWS = +- backlight and +- effects speed, FN+DEL = INS, FN + PGUP = HOME, FN + PGDN = END, FN+[{ = 19 light modes, FN+ }] = light colors.

FN in basso :

FN + 0..1 = -brightgness, +brightness, task switch, search(Win) / back to desktop(Mac), email(solo Win), Lock(Win) / search(Mac), previous, platy, next, mute

FN + - = -volume, FN + += = +volume, FN + , = calcolatrice(solo Win).

Connessioni

Per Bluettoth : mettere lo switch su BT, poi premere FN alto +Q/W/E per 5 secondi fino a quando compare un lampeggio (entrata in accoppiamento).

Per RF 2.4Ghz : mettere lo switch su BT, poi premere FN alto + P per 5 secondi fino a quando compare un lampeggio (agganciato), poi introdurre la chiavetta sulla periferica.

Per connessione con cavo mettere lo switch su OFF.